


Earphone output

Line-out cable
from soundcard

Line-in cable
to soundcard



- Antenna
- Antenna return
- 12 VDC PWR input
- GND
- switched 12 volt output
- GND
- PTT input